marbledworks

Care and Maintenance

06/2024

Disclaimer - Uniqueness of Natural Stone and Anodized Aluminum

Natural Stone:

Each piece of natural stone used in our tables is unique and inherently distinct. Variations in color, veining, texture, and pattern are natural characteristics of stone and are not considered defects. These variations highlight the natural beauty and individuality of each piece, ensuring that no two tables are exactly alike. Customers should expect and appreciate these natural differences as they add to the charm and uniqueness of the product.

Anodized Aluminum:

Our anodized aluminum components are manufactured to the highest standards. However, slight variations in color and finish may occur due to the anodizing process. These minor differences do not affect the durability or functionality of the aluminum parts but add to the unique character of each piece.

(By purchasing our natural stone tables with anodized aluminum parts, you acknowledge and accept these natural and manufacturing variations. These characteristics are a testament to the craftsmanship and natural origins of the materials used.)

Marbledworks GmbH

General Maintenance & Cleaning

06/2024

Regular Dusting:

Use a soft, dry cloth to dust both the stone and anodized aluminum parts regularly. This prevents the accumulation of dirt and grime.

Cleaning Spills Immediately:

Wipe up any spills on the stone surface immediately with a soft, absorbent cloth to prevent staining.

Natural Stone:

Daily Cleaning: Use a pH-neutral cleaner specifically designed for natural stone. Apply the cleaner with a soft cloth or sponge and wipe down the surface.

Deep Cleaning: For thorough cleaning, mix warm water with a few drops of mild dish soap. Use a soft cloth or non-abrasive sponge to clean the surface, then rinse with clean water and dry with a soft towel.

Use Coasters and Placemats:

Always use coasters, placemats, and trivets to protect the stone surface from hot items, scratches, and spills.

Handling and Moving

Lifting Properly:

Always lift the furniture; do not drag it. Dragging can damage both the stone and anodized aluminum parts.

Use Protective Pads:

Place felt or rubber pads under the furniture legs to prevent scratches on the floor and reduce stress on the joints.

Anodized Aluminum Parts:

Regular Cleaning: Use a mixture of mild dish soap and warm water. Wipe the anodized aluminum parts with a soft cloth soaked in the soapy water, then rinse thoroughly with clean water and dry with a soft cloth.

Avoid Abrasives: Do not use abrasive pads, brushes, or cleaners on anodized aluminum, as they can scratch and damage the protective anodized layer.

Stain and Residue Removal: For stubborn stains or residues, use a specialized aluminum cleaner. Apply with a soft cloth, following the cleaner's instructions, and rinse thoroughly.

By following these care instructions, your natural stone furniture with anodized aluminum parts will maintain its beauty and durability for years to come.